



Instructions for updating VBR100 player firmware

Applies to Vizio VBR100 Blu-Ray Player with Serial Number beginning with DDOEWBK and DDDOEWBK only

Burn the ISO file to a CD using software capable of burning an image disc, such as Nero Burning Rom (select Recorder...Burn Image from the menu) or ImgBurn (freeware). (Select "Write image file to disc").

1. Power on the unit, wait for the "no disc" message.
2. Eject the tray.
3. Insert the CD-R and close the tray.
4. You should see the "Loading disc" message on the screen.

DO NOT UNPLUG OR POWER OFF THE PLAYER DURING THE UPDATE!

5. When the update process is complete, the tray will open. Remove the disc from the tray, then gently push in manually on the tray so it closes.
6. Press the Power button on the player to turn off the player (the player may take up to ten seconds to respond during this process).

The firmware is now updated. You can check the revision by doing the following:

1. Power on the unit and wait for the "no disc" message
2. Open the tray
3. Enter the digits 7804 in succession on the player remote.

The screen should display all the rev numbers and you should see the "0500" label of the Loader Version.

The Firmware Update process is complete.